

iSpot Bluetooth Magic Reminder

No keys left behind... or purse, or child, or tablet. The new iSpot magic reminder device uses Bluetooth connectivity to ring your smart phone when you wander out of range of your valuables. About the size of a quarter, the iSpot can attach to a key chain or slip into your child's backpack during park outings. If the iSpot leaves your range of sight – about 20-30 feet – the reminder device will ring your smart phone and send a screen warning message. You can even give iSpot a dedicated ring tone so that you'll immediately recognize when you've left something behind. Small, simple security for the mobile age.



iSpot works the same way as other Bluetooth devices. Please follow the steps below to setup iSpot.

Step 1 Charge iSpot



Charge iSpot - iSpot uses built-in rechargeable lithium-ion battery to power its functions. When you unpack iSpot for the first time, be sure to **fully charge iSpot** for at least two (2) hours before use. The red LED light on the side of iSpot will go off when done charging. One a full-charge, iSpot works between 70-96 hours. Charge iSpot helps maintaining optimal battery health.

Charging light



Micro USB Port



Step 2 Pair iSpot



To pair iSpot with your device, refer to Bluetooth connection instruction on your device, then press-and-hold iSpot power button for 5 seconds to turn on iSpot, and then release the button. iSpot should appear on your device. Use 0000 if your device prompts for passcode.

Step 3 Download and Install iSpot App



Scan the QR code below from your mobile device to download and install iSpot App. iSpot can work without installing App. The iSpot App provides additional features like like remote paging, camera shutter.

QR Code



[iSpot Package Content](#)



iSpot backside view

